

# **KEY FEATURES**



## HORIZONTAL DROP-IN **BOBBIN SYSTEM**

Quick bobbin threading system with easy bobbin thread set up and a helpful bobbin thread cutter.



### **DIRECT STITCH SELECTION**

Effortless, direct button selection of all 310 built-in stitches.



### 10 BUTTONHOLE **STYLES**

One-step automatic buttonhole foot with 10 styles included.



## **UTILITY STITCHES WITH MEMORY FUNCTION**

Conveniently combine, save and store up to 40 stitches and names.



## **AUTOMATIC NEEDLE THREADER**

Threading the needle is effortless with the built-in Automatic Needle Threader.



## LARGE LCD DISPLAY WITH BACK-LIGHT

Bright and large LCD display.

## SEWING FEATURES



## **USEFUL ACCESSORIES**



All Purpose Foot Zipper Foot **Buttonhole Foot** Satin Stitch Foot Button Sewing Foot Overcasting Foot Blind hem Foot Hemmer Foot Gathering Foot

Cording Foot Straight Stitch Foot **Embroidery Foot** Seam Ripper / Brush Edge / Quilting Guide Twin Needle

# **UTILITY AND DECORATIVE STITCHES**

316 BUILT-IN STITCHES INCLUDING 2 ALPHABETICAL FONTS





www.necchi.us





### SPEED CONTROL

Speed control slider to easily adjust the sewing speed from slow to fast.




### START/STOP BUTTON AND LOCK STITCH BUTTON

Start and stop the machine without using the foot pedal, and sew 3 locking stitches with the press of a button.



### ADJUSTABLE PRESSER FOOT **PRESSURE**

Easily feed either lightweight fabrics or heavier fabrics with the adjustable presser foot pressure.



#### TWIN NEEDLE SEWING

Sew decorative stitches in two parallel lines with two different threads.



#### **BRIGHT LED LIGHT**

Wide sewing area with extra bright LED light.



### **EXTENSION TABLE**

The included extension table provides a larger working area when working with larger projects.

0 1 2 3 4 5 6 7 8 9 A B C D E F 016 017 018 019 020 021 022 023 024 025 026 027 028 029 030 031 032 033 GHIJKLMNOPQRSTUVWX YZabcdefghijklmnop 052 053 054 055 056 057 058 059 060 061 062 063 064 065 066 067 068 069 qrstuvwxyzÄÅÆÑÖØÇÜ 070 071 072 073 074 075 076 077 078 079 080 081 082 083 084 085 086 087 äãåæëèéêňöõøìçüũβ&

000 001 002 003 004 005 006 007 008 009 010 011 012 013 014 015 0123456789438987 016 017 018 019 020 021 022 023 024 025 026 027 028 029 030 031 032 033 YZabodefghijklmnop 052 053 054 055 056 057 058 059 060 061 062 063 064 065 066 067 068 069 r s t u v w x y z Ä Å ÆN Ö Ø ÇÜ 070 071 072 073 074 075 076 077 078 079 080 081 082 083 084 085 086 087

